

BANSHEE SHIFT DENTENT BEARING MOD INSTALLATION

1. Remove detent arm under clutch cover located next to shift cam
2. Use .170-.190" drill bit and carefully drill rivet head from detent arm as shown
3. NOTE – be careful not to drill and oversize the hole in the detent arm. Drill depth should not exceed the height of the rivet.
4. install new bearing, bolt, washer(s), and nut as shown.
5. If more than 1 washer is provided, install all between the bearing and detent arm
6. check to make sure bearing spins freely before reinstallation
7. Reinstall in engine



Due to the high performance nature and/or the fact that we are not installing this product, Mull Engineering will not be liable for any damages or injuries. Please understand that this product carries no expressed or implied warranty once installed.